

# Mini Keypad

Round

Ellipse

User Manual

# User Manual

-06-

Simplified Instruction	
Function Description	Operation
Enter the Programming Mode	<b>* - Master Code - #</b> then you can do the programming (123456 is the factory default master code)
Change the Master Code	<b>0 - New Code - # - Repeat the New Code - #</b> (code: 6 digits)
Add Card User	<b>1 - Read Card - #</b> (can add cards continuously)
Add PIN User	<b>1 - PIN - #</b> (The PIN is any 4~6 digits except 8888 which is reserved)
Delete User	<b>2 - Read Card - #</b> <b>2 - PIN - #</b>
Exit from the Programming Mode	<b>*</b>
<b>How to release the door</b>	
Card User	Read Card
PIN User	Input PIN #

- 12 -